

FIG. 1




FIG. 2

2/11




FIG. 3

3/11




FIG. 4

4/11





FIG. 5



**FIG. 6**

6/11

Stall for Next to Last PipeStage (NLP)  
 $\text{Stall}_{(NLP)} = \text{Valid Instruction in Pipe}_{(NLP)} \text{ AND } (\text{ThreadId}_{(NLP)} = \text{ThreadId of Stall})$

Stall for any other PipeStage X  
 $\text{Stall}_{(X)} = \text{Valid Instruction in Pipe}_{(X)} \text{ AND Valid Instruction in Pipe}_{(X+1)} \text{ AND Stall}_{(NLP)}$

Powerdown for any PipeStage X  
 $\text{Powerdown}_{(X)} = \text{NOT Valid Instruction in Pipe}_{(X-1)}$

Clock Enable for any PipeStage X  
 $\text{Clock}_{(X)} = \text{NOT Stall}_{(X)} \text{ AND NOT Powerdown}_{(X)}$

Clear for any PipeStage X  
 $\text{Clear}_{(X)} = \text{Clock}_{(X)} \text{ AND } [(\text{ClearThread}_{(Id0)} \text{ AND } (\text{ThreadId}_{(X-1)} = Id0)) \text{ OR } (\text{ClearThread}_{(Id1)} \text{ AND } (\text{ThreadId}_{(X-1)} = Id1))]$   
OR  
 $\text{NOT Clock}_{(X)} \text{ AND } [(\text{ClearThread}_{(Id0)} \text{ AND } (\text{ThreadId}_{(X)} = Id0)) \text{ OR } (\text{ClearThread}_{(Id1)} \text{ AND } (\text{ThreadId}_{(X)} = Id1))]$

$\text{ClearThread}_{(Id0)} = \text{There was a Clear on Thread Identification 0}$   
 $\text{ClearThread}_{(Id1)} = \text{There was a Clear on Thread Identification 1}$   
 $\text{Pipe}_{(X)} = \text{Any pipestage in the decode}$   
 $\text{Pipe}_{(X-1)} = \text{Pipestage before Pipe}_{(X)}$   
 $\text{Pipe}_{(X+1)} = \text{Pipestage after Pipe}_{(X)}$

FIG. 7

7/11




FIG. 8

8/11




FIG. 9



9/11




FIG. 10

10/11




FIG. 11A

11/11




FIG. 11B